

## Strap Anchor Instructions

Optional strap anchors are 22 gauge, 1 1/4" wide galvanized steel. Strap anchors are to be installed 6" to 8" from each corner (8 places), then 16" on center and at the meeting rail. **Strap anchors are intended as an additional fastening method, and are not a substitute for the provided jamb screws specified in the product AAMA structural report.**



For shipping, units will have the strap anchor turned inwards and fastened with one screw as shown.

After un-wrapping, turn strap anchor 180 degrees and add the second screw. Bend flat as shown.



With window in the installed position, bend to 90 degrees and secure window to opening as shown with supplied screws.